

## Template for 30500-6-1 Power Data Port



1. The surface must be accessible from both sides.
2. Surface must have a rectangular cut
3. Place power module in cutout, cord first.  
From other side of surface, slide retainer clip into module until it snaps in place. If module is loose, remove retainer clip and rotate 180° and slide back onto the module.

