



### **Instructions for Installing Piatto™ with Cube or Drum Bases**

In the factory, we do this to aid in installation:

- invert the table top on saw horses in the shop,
- pre-install the subtops to all base elements,
- place the Cubes or Drums or Panel Base on the inverted top,
- trace the base locations on the bottom of the top,
- drill pilot holes thru all the holes in the subtop,
- and package it all up for shipment.

For more information,  
contact John Kessell

**T** 410 337 3779  
**T** 800 770 7042 x809  
**F** 877 620 7411  
[jkessell@smartdesks.com](mailto:jkessell@smartdesks.com)  
[www.smartdesks.com](http://www.smartdesks.com)

On site, the installer should locate the bases in the room as required.

Take a measurement of the tracing on the bottom of the top to get approximate locations of the bases relative to each other.

Place the table top (or tops if it's a two-piece) on the bases.

Slide it around to get it properly aligned on one end (over one Cube for example).

Screw it down with screws provided. Usually only one size provided.

Then move the other base or bases to align properly....screw them down.

**IMPORTANT: lower the torque power clutch on the driver.....to keep from running the screws right thru the sub top. Be careful to not permit screw points to break thru the face of the table.**