


Liberty Task Chair - Specifications



CODE	DESCRIPTION	MEASUREMENT
a	Seat Depth (from face of lumbar to front of seat)	16.5" – 18.75"
b	Seat Height (from floor to compressed front center of seat cushion)	16" – 21" standard 15.25" – 19" low cylinder 17" – 22.25" tall cylinder 20.5" – 28.5" high cylinder chair with foot ring
c	Seat Width	21"
d	Backrest Height (from seat cushion to top of backrest)	22.5"
e	Backrest Width	20"
f	Armrest Height (from compressed seat cushion to top of armrest)	10" fixed arms 6.5 – 11.5 adjustable arms
g	Armrest Length (from face of lumbar to front of armrest)	12.25" standard
h	Distance between Armrests	19" standard
i	Height	38.5" – 43.5" standard 37.75" – 41.5" low cylinder 39.5" – 44.75" tall cylinder 43" – 51" high cylinder with foot ring
j	Base Diameter	25"
k	Chair Width	26.5"

Scope of Users

Conference/Task chair fits more than 95% of the office population

– 5'0" Woman to 6'4" Man

– 100 to 300 pounds

Users outside the standard range can be accommodated by Low or Tall Cylinder

Weight

27lbs. Conference/Task Chair

Tilt & Recline

17° recline plus 7° backrest tilt - Conference/Task Chair

Reference Angle Between Seat and Back

100° to 124°

Warranty Information

15 Years, 24/7 Warranty

Fabric/Cushions/Arm Pads: 5 Years, Single-Shift Warranty