

ITEM NO.	QTY.	PART NUMBER	TITLE
1	1	292229	GROMMET / WELD PLATE ASSEMBLY
2	1	27904	BALL CATCH
3	2	27905	PIVOT PIN
4	1	27910	STOP PAD
5	1	28193-XX	TOP LIP
6	2	27332	BUSHING
7	9	28163	EURO SCREW - HAFELLE
8	1	27919	GAS SPRING
9	1	27892	FLAT SCREEN / TILT ASSY.
10	1	29662-LH	ADJ. CABLE ARM / BALL STUD ASSY.
11	1	29661	ADJ. CABLE ARM / SCREW ASSY.
12	1	28278	CABLE BRACKET
13	5	21486	SCREW
14	4	15313	#6x3 / 4 TYPE A TRUSS HEAD
15	1	29659	T-HANDLE ACTUATOR / CABLE ASSY.

WK# 29232 - FH TOUCHSCREEN 18" KEY (1 out of 2)

March 2009

