

Template for flipIT[®] FIL-23

WK Part No.
XXXXX

For FIL with release handle, use template on top for cut-out and on underside for pull handle pilot holes.

For Top Cut-Out:

Align template edge arrow to center of user space and adhere to surface with glue stick for use.

Use 3/8" spade bit for making corner holes for cut-out. Use jig saw from corner to corner, removing the cut line with kerf of the blade.

For Bottom Pilot Holes: (release handle only)

Align template with cutout and adhere to bottom surface with glue stick.

IMPORTANT:

Use 1/8" drill with depth gauge to avoid drilling through table top !

Cut-Out is 635mm x 388.14mm
Positioned on center 127mm from user edge.

Cut-Out is 25" x 15 9/32" (25 x 15.281)
Positioned on center 5" from user edge.

